

The latching procedure for the GG style nozzle differs slightly from the old LG style nozzle. The design was modified so that the latching feature could be used with one hand only. The pictures below will guide you through the simple process of latching a GG style nozzle. **Green = User input** **Red = Automatic (spring)**



Once the nozzle is securely attached to the fill point, pull Lever open to allow flow.



When Lever is pulled until it touches the 'Comfi-grip' prepare to latch the Lever with your forefinger.



Pull latch with forefinger.



Hold latch with forefinger and release Lever with remaining fingers. The nozzle is now latching and the valve is held open to allow full flow.



To unlatch Lever, squeeze Lever and latch will automatically unhook itself from latch pin.



User can now safely lower the lever to close the valve. Caution: A small discharge of gas is released from connector nut, please keep hands away. Once gas is dispersed the nozzle can now be removed.